

BMW X3 – 2018 to present

OUR REF: H0696

PACKAGING REQUIREMENTS.

CARGO LINER

- **2 x 470mm** 30mm wide self-adhesive loop fastener
- **2x 450mm** 30mm wide self-adhesive loop fastener

LIFTGATE COVER

- **18 x tabs** self-adhesive loop fastener



Rear split, prepared for bumper flap and Cargo liner extension



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all the **SILICONE** applied during manufacture and detailing.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 to 2 if necessary) Extra tabs have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.



**The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*

STEP 1. PREPARATIONS

- Remove the cargo cover. It may be replaced later.
- Set your rear seats to be fully reclined.
- Put the headrests in their highest position. (Image A)



STEP 2. INSTALLING THE BASE

- Place the cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the back side attach directly to the carpet. (Image B)



STEP 3. INSTALLING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image C)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (Image D). Make sure to hold the front part of the base in position to avoid pulling the cargo liner too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the upper part of the rear seats. (Please refer to **REAR PLUS / SPLIT** options on website to see detailed photo)



STEP 4. INSTALLING THE SIDES

- Attach the hook fastener on the top edge of the Cargo liner side (**highlighted in orange - Image E**) directly to the carpet along the top edge of the carpeted sides of the cargo area.
- Stick the 470mm self adhesive loop fastener strip onto the plastic panel located at the liftgate end of the side of the cargo area and in line with the hook fastener on the back side of the Cargo liner (**highlighted in orange - Image F**) Repeat on opposite side.



IMAGE E



IMAGE F

STEP 5. INSTALLING THE BACK

- Attach one 450mm self adhesive loop fastener strip on each side in line with the hook fastener sewn on the back side of the Cargo liner. (**highlighted in blue - Image G**)
- Fasten the Cargo liner to it using the hook fastener sewn on the reverse part of the liner.



IMAGE G

OPTIONAL EXTRAS

Please note: *the following photos are not specific to your vehicle*

STEP 5A. LIFTGATE COVER

- Line up the Liftgate Cover with the liftgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. [\(Image 1\)](#)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5B. BUMPER FLAP

- Install the Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner. [\(Image 2\)](#)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5C. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection for the rear seats when purchased in with a REAR PLUS option.(Image 6)

- The Cargo Liner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It does not offer full protection to the rear doors



The Bumper Flap 5B and the Cargo Liner Extension 5C cannot be added at a late date

STEP 5E. FREQUENT USE KIT

- If you frequently remove/install your Cargo liner from/to your vehicle, please note that the carpet will “fluff” up – we offer an alternative Frequent Use Installation Kit (Image 7+8)

The Frequent Installation Kit is available to buy from our on-line store – simply add it to your order from the store. The kit can also be ordered at a later date.

